

FUEL INJECTOR USA

FUEL INJECTION SOLUTIONS

| OEM | APPLICATIONS |
|-----------------------------------|---|
| 1 9 260 930 013 35310-23600 | HYUNDAI ELANTRA (07-01) / HYUNDAI SANTA FE (-9-07) / HYUNDAI TUBURON (08-03) / HYUNDAI TUCSON (-9-05) / KIA OPTIMA (09-06) / KIA RONDO (09-07) / KIA SPECTRA / SPECTRA5 (-9-04) / KIA SPORTAGE (09-05)(COLOR BLANCO) KIT 002 6 KIT 043 |
| 2 25332290 96 334 808 | CHEVROLET OPTRA Y DAEWOO LANOS (INYECTOR DELPHI) KIT 015 6 KIT 044 |
| 3 9 250 930 011 35310-33310 | HYUNDAI ELANTRA (95-94) / HYUNDAI SONATA (98-94) KIT 003 6 KIT 004 |
| 4 CDH 240 | MITSUBISHI LANCER 2002 (BEIG) / CHRYSLER SEBRING (05-01) / DODGE STRATUS (05-01) / MITSUBISHI ECLIPSE (05) / MITSUBISHI GALANT (03-00) KIT 028 |
| 5 0 280 150 931 | FORD AEROSTAR (96) / FORD EXPLORER / SPORT / SPORT TRAC (96-93) / FORD RANGER (96-93) / MAZDA NAVAJO (94-93) / MAZDA PICKUP (96-94) / FORD EXPLORER 96-97 4.0 LTS (ROJO Y NEGRO) KIT 034 |



| | | |
|----|----------------------|--|
| 6 | INP 061 | MITSUBISHI DIAMANTE 3.0 LTS (VERDE CLARO) / DODGE STEALTH (93-91) / MITSUBISHI 3000 GT (96-91) KIT 004 |
| 7 | 12571863 | CHEVROLET CAVALIER Z24 2.2 LTS PONTIAC SUN FIRE 2.2 LTS (INYECTOR DELPHI) / CHEVROLET CAVALIER (02-00) / PONTIAC SUNFIRE (00) / PONTIAC SUNFIRE (02-00) KIT 015 ó KIT 044 |
| 8 | 23250-20010 | TOYOTA CAMRY 3.0 LTS / LEXUS 3.0 LTS (AZUL) / LEXUS ES300 (01-94) / TOYOTA AVALON (99-95) / TOYOTA CAMRY (01-94) / TOYOTA SIENNA (00-98) / TOYOTA SOLARA (03-99) KIT 026 |
| 9 | 1F2E B4A 9F593212 | MUSTANG 2001 V6 3.8 LTS (NEGRO) / FORD F-150 (02-99) / FORD MUSTANG (04-01) / FORD RANGE (04-01) / FORD TAURUS (05-01) / FORD WIDSTAR (03-99) / MAZDA B3000 (03-01) |
| 10 | 0 280 158 028 | CHRYSLER SEBRIN 2005 2.7 LTS (NEGRO) / CHRYSLER 300 SERIES (09-05) / CHRYSLER PACIFICA (08-05) / CHRYSLER SEBRING (09-04) / CHRYSLER TOWN & COUNTRY (09-08) / DODGE AVENGER (-9-08) / DODGE CARAVAN / GRANS CARAVAN (-9-08) / DODGE CHALLENGER (09) / DODGE CHARGER (09-06) / DODGE MAGNUM (08-05) / DODGE NITRO (09-07) / DOSGE STRATUS (06-04) KIT 002 |
| 11 | 23250-16150 | TOYOTO COROLLA 1.6 LTS (BEIG) / GEO PRIZM (97-93) / TOYOTA COROLLA (97-93) KIT 010 |



| | | |
|----|----------------------|--|
| 12 | 23250-74060 | TOYOTA CAMRY 87 2.0 LTS (AZUL OSCURO) / TOYOTA CAMRY (91-88) / TOYOTA CELICA (89-88) KIT 010 |
| 13 | 4390 | NISSAN ALTIMA (06-02) / NISSAN SENTRA (06-02) |
| 14 | 000 078 8323 | MERCEDES BENZ 400 SERIES (93-92) / MERCEDES BENZ 500 SERIES (93-92) / MERCEDES BENZ CL CLASS (99-98) / MERCEDES BENZ E CLASS (97-94) / MERCEDES BENZ S CLASS (99-94) / MERCEDES BENZ SL CLASS (98-94) |
| 15 | 12582219 | CHEVROLET COBALT (09-05) / PONTIAC G5 (09-07) / PONTIAC PURSUIT (06) |
| 16 | 0 280 155 962 | FORD EXPLORER ANO 98 4.0 LTS (BLANCO) / FORD AEROSTAR (97) / FORD RANGER (97) / MAZDA PICKUP (99-97) KIT 001 ó KIT 047 |
| 17 | 1F1E D4B 9F593214 | MUSTANG 2001 V6 3.8 LTS (NEGRO) / FORD F-150 (02-99) / FORD MUSTANG (04-01) / FORD RANGE (04-01) / FORD TAURUS (05-01) / FORD WIDSTAR (03-99) / MAZDA B3000 (03-01) |



| | | |
|----|---------------|--|
| 18 | 23250-0D050 | PONTIAC VIBE (08-05) TOYOTA COROLLA (08-05) TOYOTA MATRIX (08-05) KIT 027 |
| 19 | INP-065 | MITSUBISHI GALANT 2.0 LTS (AZUL) / EAGLE SUMMIT (95) / MITSUBISHI ECLIPSE (99-96) / MITSUBISHI EXPO (95-92) / MITSUBISHI EXPO LRV (94-93) / MITSUBISHI GALANT (98-94) / PLYMOUTH COLT (94-93) KIT 029 ó KIT 011 |
| 20 | 23250-0A020 | TOYOTA CAMRY XLE 2004 (ROSADO) / LEXUS ES300 (03-02) / LEXUS ES330 (06-04) / LEXUS RX330 (06-04) / LEXUS RX400H (08-06) / TOYOTA CAMRY (06-02) / TOYOTA HIGHLANDER (07-04) / TOYOTA SIENNA (06-04) / TOYOTA SOLARA (08-04) KIT 029 |
| 21 | 25322180 | CHEVY OLDSMOBILE 3.4 (00-05) KIT 015 ó KIT 044 |
| 22 | 195500-2040 | MAZDA MX3 1.6 LTS (GRIS) / KIA SEPHIA (95-94) / MAZDA 323 (91-90) / MAZDA MX3 (93-92) / MAZDA PROTÉGÉ (94-90) KIT 010 |
| 23 | 0 280 156 036 | CHRYSLER CONCORDE (04-01) / CHRYSLER INTREPID (03-01) / CHRYSLER SEBRING (04-01) / DODGE INTREPID (04-01) / DODGE STRATUS (04-01) KIT 002 ó KIT 043 |



| | | |
|----|---------------|--|
| 24 | 0 280 155 887 | FORD FOCUS / FORD SCAPE (GRIS CLARO) / FORD CONTOUR (00-99)/ FORD ESCAPE (04-01) / FORD FOCUS (04-00) / MAZDA TRIBUTE (04-01) / MERCURY COUGAR (02-99) / MERCURY MYSTIQUE (00-99) KIT 002 ó KIT 043 |
| 25 | 0 280 156 193 | MAZDA 3 (04-05) 2.3 LTS / MAZDA 5 (06-07) 2.3 LTS / MAZDA 6 (03-04) 2.3LTS KIT 002 ó KIT 043 |
| 26 | 23250-74100 | TOYOTA CAMRY (00-92) / CELICA (99-92) / MR2 (95-92) / RAV 4 (00-98) / SOLARA (00-99) / 2,2 LTS KIT 010 |
| 27 | FJ581 | ACURA (97) / NSX (94-91) / INTEGRA (91-86) / LEGEND (95) / VIGOR (94-92) / ACCORD (97-86) / CIVIC (91-88) / CRX (19-88) / ODYSSEY (97-95) / PRELUDE (96-85) / OASIS (97-96) / STERLING 825 (88-87) (2.2 LTS) KIT 014 Universal ó KIT 014 Original |
| 28 | FBY 2850 | NISSAN CUBE (10-09) / NISSAN SENTRA (10-07) / NISSAN VERSA (10-07) / NISSAN TIDA KIT 002 |
| 29 | 195500-3170 | MITSUBISHI MONTERO SPORT (01-97) KIT 020 |



| | | |
|----|---------------------------------|--|
| 30 | 25323972 | BUICK LESABRE SEDAN /COUPE (05-01) / BUICK PARK AV (05-01) / BUICK REGAL SEDAN / COUPE (04-01) / CHEVROLET CAMARO (02-00) / CHEVROLET IMPALA (05-00) / CHEVROLET MONTE CARLO (05-00) / PONTIAC BONEVILLE (05-01) / PONTIAC FIREBIRD (02-00) / PONTIAC GRAN PRIX (02-01) <i>KIT 030 ó KIT 045</i> |
| 31 | 5235136 17084888 17089569 | BUICK CENTURY SEDAN (93-87) / BUICK REGAL SEDAN (93-88) / BUICK SKYLARK (93-89) / CADILLAC CIMARRON (88-87) / CHEVROLET BERETTA (93-87) / CHEVROLET CAMARO (92-85) / CHEVROLET CAVALIER (94-87) / CHEVROLET CELEBRITY (90-85) / CHEVROLET CORSICA (93-87) / CHEVROLET LUMINA (94-90) / OLDSMOBILE ACHIEVA (93-92) / OLDSMOBILE CALAIS / CUTLAS CALAIS (91-89) / OLDSMOBILE CIERA / CUTLAS SUPREME (93-88) / OLDSMOBILE FIRENZA (87) / PONTIAC 6000 (91-85) / PONTIAC FIREBIRD (92-85) / PONTIAC GRAND AM (93-92) / PONTIAC GRAND PRIX (93-88) / PONTIAC SUNBIRD (94-91) / PONTIAC TEMPEST (91-87) <i>KIT 001</i> |
| 32 | 195500-2110 | FORD FESTIVA 1.3 LTS (93-90) <i>KIT 010</i> |
| 33 | 9 260 930 003 35310-38010 | HYUNDAI ACCENT (05-00) <i>KIT 002 ó KIT 043</i> |
| 34 | 0 280 155 757 | MERCEDES BENZ C CLASS (97-94) / MERCEDES BENZ E CLASS (97) / MERCEDES BENZ S CLASS (99-97) / MERCEDEZ BENZ SL CLASS (97) <i>KIT 001 ó KIT 047</i> |



| | | |
|----|---------------|---|
| 35 | 23250-15040 | TOYOTA COROLLA 98-99 NEW SENSATION 4AFE 1,6 LTS KIT 010 |
| 36 | 0 280 155 705 | FORD ESCORT (03-97) / MERCURY TRACER (97) KIT 002 ó KIT 043 |
| 37 | 0 280 155 917 | FORD CROWN VICTORIA (04-01) / LINCOLN TWON CAR (02-01) / MERCURY GRAN MARQUIS (02-01) |
| 38 | 0 280 150 203 | BMW 318 (94-91) / BMW 535 (93-85) / BMW 635 (89-85) / BMW 735 (92-85) / BMW L (87-86) FORD BRONCO (91-85) / FORD E SERI VAN (99-86) / FORD F SERIE PICK UP (91-85) / FORD MUSTANG (95-86) / FORD THUNDERBIRD (93-91) / LINCOLN MARK (92-90) / MERCURY CAPRI (86) / MERCURY COUGAR (93-91) KIT 002 / KIT 021 / KIT 031 / KIT 005 |
| 39 | 17120683 | DAEWOO TACUMA Y LEGANZA / BUICK LESABRE SEDAN / COUPE (95-83) / CADILLAC DEVILLE (95-94) / CHEVROLET CAPRICE (96-94) / CHEVROLET LUMINA APV (96-93) / CHEVROLET VENTURE (99-97) / DAEWOO LEGANZA (92-99) / DAEWOO NUBIRA (92-99) / OLDSMOBILE ALERO (99) / OLDSMOBILE DELTA 88 (94-93) / OLDSMOBILE SILHOUETTE (99-93) / PONTIAC BONNEVILLE (94-93) / PONTIAC GRAN AM (99) / PONTIAC MONTANA (99) / PONTIAC TRANSPORT (98-93) KIT 002 |



| | | |
|----|-------------|--|
| 40 | INP 066 | CHRYSLER DAYTONA (93-92) / CHRYSLER LEBARON (95-92) / CHRYSLER VOYAGER / GRAND VOYAGER (00) / DODGE CARAVAN / GRAND CARAVAN (00-92) / DODGE DAYTONA (93/92) / DODGE DYNASTY (93-92) / DODGE SHADOW (94-92) / DODGE SPIRIT (95-92) / PLYMOUTH ACCLAIM (95-92) / PLYMOUTH SUNDANCE (94-92) / PLYMOUTH VOYAGER / GRAN VOYAGER (00-92) KIT 001 |
| 41 | 195500-2350 | SUZUKY STEEM (95-97) KIT 010 |
| 42 | JSEJ5 | CHEVROLET LUV (ROJOS) |
| 43 | 23250-66010 | TOYOTA MACHITO Y TOYOTA AUTANA 4.5 LTS (00-01) |
| 44 | 23250-50010 | LEXUS LS 400 (92-90) KIT 004 ó KIT 029 |
| 45 | 23250-11010 | TOYOTA TERCEL (94-91) KIT 010 |



| | | |
|----|---------------|---|
| 46 | 23250-31080 | <p>SCION TC (10-05) / SCION XB (10-08) / TOYOTA CAMRY (09-04) / TOYOTA COROLLA (10-09) / TOYOTA HIGHLANDER (07-04) / TOYOTA MATRIX (10-09) / TOYOTA RAV 4 (08-04) / TOYOTA SOLARA (08-04)</p> <p>KIT 059</p> |
| 47 | 0 280 156 041 | <p>FORD CONTOUR (00-99) / FORD EXPEDITION (04-03) / FORD COUGAR (99) / MERCURY MYSTIQUE (99)</p> <p>KIT 021 ó KIT 048</p> |
| 48 | 0 280 155 784 | <p>CHRYSLER CIRRUS (00) / CHRYSLER SEBRING (98) / CHRYSLER VOYAGER / GRAND VOYAGER (00) / DODGE CARAVAN / GRAND CARAVAN (00-98) / DODGE NEON (99-98) / DODGE STRATUS (00-98) / PLYMOUTH BREEZE (00-98) / PLYMOUTH NEON (99-98) / PLYMOUTH VOYAGER / GRAND VOYAGER (00-98)</p> <p>KIT 002 / KIT 001 / KIT 021 / KIT 043 / KIT 047 / KIT 048</p> |
| 49 | 25166922 | <p>ACURA SLX (99-98) / HONDA PASSPORT (02-98) / ISUZU AMIGO (00-98) / ISUZU RODEO (02-98) / ISUZU RODEO SPORT (03-01) / ISUZU TROPPER (02-98)</p> <p>KIT 039 ó KIT 045</p> |
| 50 | 23250-62030 | <p>LEXUS ES300 (93-92) / TOYOTA 4RUNNER (98-96) / TOYOTA CAMRY (93-92) / TOYOTA T100 (98-95) / TOYOTA TACOMA (98-95)</p> <p>KIT 026</p> |
| 51 | 23250-21020 | <p>SCION XA (06-03) / SCION XB (06-03) / TOYOTA ECHO (05-00) / TOYOTA PRIUS (09-01) / TOYOTA YARIS</p> <p>KIT 027</p> |



| | | |
|----|------------------------------|---|
| 52 | 23250-74140 | Toyota Camry (99-94) / Toyota Celica (99-94) / Toyota RAV4 (00-96) / Toyota Solara (99) KIT 010 |
| 53 | INP 063 | DODGE COLT (94-92) / EAGLE SUMMIT (96-93) / MITSUBISHI EXPO LRV (94-92) / MITSUBISHI MIRAGE (96-93) / PLYMOUTH COLT (94-92) KIT 011 |
| 54 | 0 280 155 972 | DODGE PICKUP - FULLSIZE / RAMCHARGE (03-02) / JEEP LIBERTY (03-02) KIT 001 / KIT 047 |
| 55 | 9 250 930 003 35310-24010 | DODGE COLT (94-92) / EAGLE SUMMIT (96-93) / EAGLE VISTA (90) / HYUNDAI EXCEL (94-90) / HYUNDAI SCOUPE (93-91) / MITSUBISHI MIRAGE (90-98) / MITSUBISHI PRECIS (94-90) / PLYMOUTH COLT (94-92) KIT 004 |
| 56 | NISSAN MAXIMA FJ142 | NISSAN 300 ZX (93-90) KIT 057 |
| 57 | 195500-3110 | FORD LASER 2001 / MAZDA ALLIEGRO 2001 / MAZDA PROTÉGÉ (01-97) KIT 010 |



| | | |
|----|----------------------|---|
| 58 | CDH 166 | MITSUBISHI MIRAGE (02-97) <i>KIT 028 ó KIT 029</i> |
| 59 | 0 280 155 710 | FORD CONTOUR (99) / FORD CROWN VICTORIA (00) / FORD E SERIE VAN (03-00) / FORD E SERIE MEDIUM DUTY VAN (03) / FORD EXCURSION (05-00) / FORD F SERIE PIC UP (04-00) / LINCOLN TWON CAR (04-00) / MERCURI GRAND MARQUIS (04-00) <i>KIT 001 / KIT 021 / KIT 047 / KIT 048</i> |
| 60 | 0 280 158 005 | NISSAN ALTIMA (06-04) / NISSAN MAXIMA (08-03) / NISSAN MURANO (04) / NISSAN QUEST (09-04) <i>KIT 002 SF</i> (Sin Filtro) |
| 61 | 17091782 17091728 | NO LO SE |
| 62 | 23250-16120 | GEO PRIZM (92-90) / TOYOTA CELICA (93-90) / TOYOTA COROLLA (92-90) <i>KIT 010</i> |
| 63 | 0 280 158 042 | INFINITY FX 35 (08-05) / INFINITY G35 (07-04) / INFINITY M35 (08-06) / NISSAN 350 Z (06-05) / NISSAN MURANO (07-04) <i>KIT 002 SF</i> (Sin Filtro) |



| | | |
|----|--------------------------------|---|
| 64 | NISSAN SENTRA ROJO A4600 | INFINITY G20 (94-91) / NISSAN PULSAR NX (93-91) / NISSAN SENTRA (94-91) KIT 060 ó KIT 060 FULL |
| 65 | 0 280 155 715 | FORD TAURUS (98-96) / MERCURY SABLE (98-96) KIT 001 ó KIT 047 |
| 66 | 23250-0D040 | CHEVROLET PRIZM (02-00) / PONTIAC VIVE (04-03) / TOYOTA CELICA (05-00) / TOYOTA COROLLA (04-00) / TOYOTA MATRIX (06-03) / TOYOTA MR2 SPIDER (05-00) KIT 027 |
| 67 | 23250-46030 | TOYOTA PREVIA (95-91) |
| 68 | 1427240 | BMW 320 (05-01) / BMW 323 (00-98) / BMW 325 (06-01) / BMW 328 (00-99) / BMW 525 (05-01) / BMW 528 (00-99) / BMW X (05-04) / BMW Z (05-99) KIT 015 |
| 69 | 23250-50040 | LEXUS GX470 (05-03) / LEXUS LX470 (05-98) / TOYOTA FOUR RUNNER (04-03) / TOYOTA LAND CRUISER (05-98) / TOYOTA SEQUOIA (04-01) / TOYOTA TUNDRA (04-00) KIT 020 |



| | | |
|----|---------------|--|
| 70 | 0 280 155 734 | FORD EXPLORER / SPORT / SPORT TRAC (98-97) / MERCURY MONTAINEER (98) KIT 002 / KIT 001 / KIT 043 / KIT 047 |
| 71 | 4612402 | CHRYSLER IMPERIAL (93-92) / CHRYSLER NEW YORKER (93-92) / CHRYSLER TOWN AND COUNTRY (00-94) / CHRYSLER VOYAGER / GRAND VOYAGER (00) / DODGE CARAVAN / GRAND CARAVAN (00-94) / PLYMOUTH VOYAGER AND GRAND VOYAGER (00-94) KIT 001 |
| 72 | OK30E13250 | KIA RIO / RIO 5 (04-01) KIT 015 |
| 73 | JS28-2 | HONDA PASSPORT (95-94) / ISUZU AMIGO (94) / ISUZU PICKUP (95-94) / ISUZU RODEO (95-94) KIT 052 |
| 74 | 1976 | BUICK CENTURY SEDAN COUPE (96-93) / CHEVROLET BERETTA (96-92) / CHEVROLET CAVALIR (97-92) / CHEVROLET CORSICA (96-92) / CHEVROLET LLV (POSTAL VEHICLE) (95-94) / CHEVROLET LUMINA (93) / CHEVROLET S10 PICKUP (97-94) / GMC S15 PICKUP (97-94) / ISUZU HOMBRE (97-92) / OLDSMOBILE CIERA / CUTLASS CIERA (96-93) / PONTIAC SUNFIRE (97-95) KIT 012 |
| 75 | 4591308 | CHRYSLER 300 SERIES (99) / CHRYSLER CONCORDE (99-98) / CHRYSLER INTREPID (99-98) / CHRYLER LHS (99) / DOSGE INTREPID (99-98) / PLYMOUTH PROWLER (99) KIT 001 |



| | | |
|----|----------------------|---|
| 76 | INP 052 | MITSUBISHI PANNEL |
| 77 | 4L3E-B4C 9F593191 | FORD E SERIES FULLSIZE VAN (08-05) / FORD EXPLORER / SPORT / SPORT TRAC (05) / FORD F SERIES FULLSIZE PICKUP (08-05) / MERCURY MONTAINEER (05-04) KIT 021 |
| 78 | 23250-16160 | GEO PRIZM (97-93) / TOYOTA CELICA (97-94) / TOYOTA COROLLA (97-93) KIT 010 |
| 79 | 0 280 155 034 | PEUGEOT 206 (02) |
| 80 | 53032145AA | DODGE DAKOTA (07-01) / DODGE DURANGO (07-01) / DODGE PICKUP FULL SIZE / RAMCHARGER (07-02) / JEEP COMMANDER (07-06) / JEEP GRAND CHEROKEE (07-01) KIT 001 ó KIT 021 |
| 81 | FBJC100 | INFINITI FX35 (04-03) / INFINITI G35 (04-03) / NISSAN 350 Z (04-03) / NISSAN PTHFINDER (04-03) KIT 002 ó KIT 043 |



| | | | |
|----|-----------------------------|---|---|
| 82 | 96334808 | CHEVROLET AVEO OPTRA Y DAEWOO (06-04) <i>KIT 015 ó KIT 044</i> |  |
| 83 | 35310-23700 | HYUNDAI ELANTRA (06-04) / KIA SPECTRA / SPECTRA 5 (06-04) <i>KIT 010</i> |  |
| 84 | HONDA PUNTA PLASTICA LARGA | ACURA RSX (06-05) / HONDA ACCORD (07-03) / HONDA CR-V (09-05) / HONDA ELEMENT (08-03) |  |
| 85 | 53030842 | DODGE DAKOTA (00) / DODGE DURANGO (00) / JEEP GRAND CHEROKEE (00-99) <i>KIT 021</i> |  |
| 86 | 12582704 | CHEVROLET COBALT (06-05) / CHEVROLET COBALT (07) / CHEVROLET HHR (06) / CHEVROLET HHR (07) / CHEVROLET MALIBU / MALIBU MAXX (08-06) / PONTIAC G5 (07) / PONTIAC G6 (07) / PONTIAC SOLSTICE (07-06) / SATURN AURA (07) / SATURN ION (07-05) / SATURN ION (07-06) / SATURN SKY (07) / SATURN VUE (06) / SATURN VUE (07) |  |
| 87 | 9 260 930 008 0K2A513250 | KIA SEPHIA (01-98) / KIA SPECTRA / SPECTRA 5 (04-00) <i>KIT 002 ó KIT 043</i> |  |

| | | |
|----|----------------------------|--|
| 88 | 04591658AA | <p>CHRYLER 300 SERIES (04-00) / CHRYLER CONCORDE (04-00) / CHRYLER INTREPID (03-00) / CHRYSLER LHS (01-00) / CHRYLER PROWLER (02-01) / DODGE INTREPID (04-00) / PLYMOUTH PROWLER (01-00)</p> <p>KIT 001</p> |
| 89 | 0 280 150 973 | <p>BUICK PARK AVENUE (97-95) / BUICK REGAL SEDAN / COUPE (00-96) / BUICK RIVIERA (97-95) / BUICK LUMINA (99-98) / CHEVROLET MONTE CARLO (99-98) / OLDSMOBILE 98 / 98 REGENCY (96-95) / OLDSMOBILE DELTA 88 (95) / OLDSMOBILE INTRIGUE (99-98) / PONTIAC BONNEVILLE (95) / PONTIAC GRAND PRIX (00-97)</p> <p>KIT 001 ó KIT 021</p> |
| 90 | F47E A2F | <p>FORD AEROSTAR (97-92) / FORD PROBE (92-91) / FORD RANGER (01-92) / FORD TAURUS (99-91) / FORD TEMPO (94-92) / FORD WISTAR (00-95) / FORD PICKUP (01-94) / MERCURY SABLE (99-91) / MERCURY TOPAZ (94-92)</p> <p>KIT 001 ó KIT 034</p> |
| 91 | 0 280 155 209 000787323 | <p>MERCEDES BENZ 300 SERIE (93) / MERCEDES BENZ C CLASS (98-94) / MERCEDES BENZ E CLASS (96-94) / MERCEDES BENZ S CLASS (96-94) / MERCEDES BENZ SL CLASS (96-94)</p> <p>KIT 002 / KIT 001 / KIT 021</p> |
| 92 | 0 280 156 014 | <p>CHRYLER CROSSFIRE (08-04) / MERCEDES BENZ C CLASS (05-01) / MERCEDES BENZ CLK CLASS (05-01) / MERCEDES BENZ E CLASS (05-01) / MERCEDES BENZ ML CLASS (03-01) / MERCEDES BENZ SLK CLASS (04-01)</p> <p>KIT 002 / KIT 001 / KIT 043 / KIT 047</p> |
| 93 | XL5E-B2A | <p>FORD RANGE (00-98) / MAZDA PICKUP (98)</p> |



| | | |
|----|---------------|--|
| 94 | 23250-46050 | LEXUS GS300 (97-93) / LEXUS SC300 (97-94) / TOYOTA SUPRA (97-93) KIT 026 |
| 95 | CDH 210 | CHRYSLER SEBRING (05-01) / DODGE STRATUS (05-01) / MITSUBISHI ECLIPSE (05-00) / MITSUBISHI GALANT (03-00) / MITSUBISHI LANCER (03-02) / MITSUBISHI MIRAGE (02-97) / MITSUBISHI MONTERO SPORT (03-02) KIT 029 |
| 96 | 0 280 155 771 | FORD CONTOUR (00-98) / MERCURY COUGAR (99) / MERCURY MYSTIQUE (00-98) KIT 021 ó KIT 048 |
| 97 | 3290 | SUZUKI O CHEVROLET STEEM (00-98) KIT 010 |
| 98 | 0 280 155 934 | DOSGE DAKOTA (03-00) / DODGE DURANGO (03-00) / DODGE PICKUP FULLSIZE / RAMCHARGER (03-00) / DODGE VAN FULLSIZE (03-00) KIT 001 / KIT 021 / KIT 047 / KIT 048 |
| 99 | 0 280 156 205 | FORD RANGE XLT 2.3 LTS (06-04) KIT 021 ó KIT 048 |



| | | |
|-----|---------------|---|
| 100 | 0 280 155 900 | FORD EXPLORER / SPORT / SPORT TRAC (01-99) / MERCURY MONTAINEER (99) |
| 101 | 0 280 150 561 | FORD BRONCO (96-90) / FORD CROWN VICTORIA (97-92) / FORD E SERIE FULLSIZE VAN (04-90) / FORD E SERIE MEDIUM DUTY VAN (03) / FORD EXCURSION (05-00) / FORD EXPEDITION (02-97) / FORD F SERIE FULLSIZE PICKUP (03-89) / FORD MUSTANG (04-96) / FORD THUNDERBIRD (94) / LINCOLN NAVIGATOR (99-98) / LINCOLN TOWN CAR (94-91) / MERCURY COUGAR (94) / MERCURY GRAND MARQUIS (97-92) <i>KIT 021 ó KIT 005</i> |
| 102 | 0 280 155 796 | CHRYSLER PT CRUISER (03-01) / CHRYSLER SEBRING (04-01) / CHRYSLER VOYAGER / GRAND VOYAGER (03-01) / DODGE CARAVAN / GRAND CARAVAN (03-01) / DODGE NEON (03-01) / DODGE STRATUS (04-01) / PLYMOUTH NEON (01) <i>KIT 002 ó KIT 043</i> |
| 103 | 23250-11110 | TOYOTA PASEO (99-95) / TOYOTA TERCEL (99-95) <i>KIT 010</i> |
| 104 | 0 280 155 974 | FORD FOCUS 2000 <i>KIT 002 ó KIT 043</i> |



| | | |
|-----|--------------------|--|
| 105 | 0 280 150 034 | JAGUAR XJS (92) / MERCEDES BENZ 300 SERIE (71-70) / MERCEDES BENZ 350 SERIE (72) / SAAB 99 (70) / VOLKSWAGEN 411 (72-71) / VOLKSWAGEN 412 (73) / VOLKSWAGEN FASTBACK (73-70) / VOLKSWAGEN SQUAREBACK (73-78) KIT 024 ó KIT 025 |
| 106 | FJ485 | ACURA MDX (06-03) / ACURA TL (08-04) / HONDA ACCORD (07-03) / HONDA FIT (07) / HONDA ODYSSEY (09-05) / HONDA PILOT (09-05) / HONDA RIDGELINE (09-06) KIT 002 |
| 107 | HONDA TIPO 208 | HONDA CIVIC (05-01) KIT 002 |
| 108 | 1010355 HDB305F | MITSUBISHI ECLIPSE (10-06) / MITSUBISHI ENDEAVOR (06- 04) / MITSUBISHI GALANT (09-04) KIT 027 |
| 109 | 0 280 155 791 | VOLKSWAGEN BEETLE (01-98) / VOLKSWAGEN JETTA (01- 00) KIT 015 |
| 110 | 0 280 156 203 | KIT 002 ó KIT 043 |



| | | |
|-----|---------------|--|
| 111 | 0 280 155 825 | AUDI A4 SERIE (00) / VOLKSWAGEN PASSAT (01-00) KIT 015 |
| 112 | 0 280 156 046 | FORD FOCUS (04-01) KIT 002 ó KIT 043 |
| 113 | 0 280 155 859 | FORD ESCORT (00-99) / MERCURY TRACER (99) KIT 002 ó KIT 043 |
| 114 | 23250-03010 | TOYOTA CAMRY (01-00) / TOYOTA SOLARA (00) KIT 010 ó KIT 020 |
| 115 | 0 280 156 162 | FORD ECO SPORT 2007 / FORD FOCUS / MAZDA TRIBUTE 2.3 LT |
| 116 | 0 280 155 742 | MERCEDES BENZ C CLASS (00-98) / MERCEDES BENZ CLK CLASS (00-98) / MERCEDES BENZ E CLASS (00-98) / MERCEDES BENZ ML CLASS (00-98) KIT 002 / KIT 001 / KIT 021 / KIT 043 / KIT 047 / KIT 048 |



| | | |
|-----|--------------------|---|
| 117 | 25321267 | CHEVROLET CAVALIER (02-00) / PONTIAC SUNFIRE (00) / PONTIAC SUNFIRE (02-00) <i>KIT 015 ó KIT 044</i> |
| 118 | FBJC101 | INFINITY FX45 (08-03) / INFINITY I35 (04-02) / INFINITY M45 (09-03) / INFINITY Q45 (06-03) / NISSAN ALTIMA (03-02) / NISSAN MAXIMA (03-02) / NISSAN MURANO (03) <i>KIT 002 ó KIT 043</i> |
| 119 | NADA | |
| 120 | 25334150 | CHEVROLET AVEO OPTRA 1,6 LTS |
| 121 | F43E-A2C CM4781 | FORD CONTOUR (97-95) / MERCURY MYSTIQUE (97-95) |
| 122 | 17089625 | CHEVROLET COBALT (06-05) / CHEVROLET COBALT (07) / CHEVROLET HHR (06-07) / CHEVROLET MALIBU / MALIBU MAXX (08-06) / PONTIAC G5 (07) / PONTIAC G6 (07) / PONTIAC SOLSTICE (07-06) / SATURN AURA (07) / SATURN ION (07-05) / SATURN SKY (07) / SATURN VUE (07-06) |



| | | |
|-----|------------------------------|---|
| 123 | 0 280 150 965 | DODGE AVENGER (99-95) / DODGE NEON (96-95) / EAGLE TALON (98-95) / MITSUBISHI ECLIPSE (99-96) / PLYMOUTH NEON (96-95) / HYUNDAI ACCENT (02) KIT 002 ó KIT 034 |
| 124 | NADA | |
| 125 | 0 280 155 832 | VOLVO S80 (01-99) KIT 001 ó KIT 047 |
| 126 | 9 260 930 006 35310-22600 | HYUNDAI ACCENT (05-00) KIT 002 ó KIT 043 |
| 127 | 23250-75040 | TOYOTA TACOMA (00-95) KIT 010 |
| 128 | 17091654 | CHEVROLET CORVETTE (96) / CAVALIER Z24 KIT 002 / KIT 001 / KIT 021 |



| | | |
|-----|---------------|---|
| 129 | 23250-0A010 | LEXUS ES300 (01-98) / LEXUS RX300 (03-99) / TOYOTA AVALON (04-98) / TOYOTA CAMRY (01-98) / TOYOTA HIGHLANDER (03-01) / TOYOTA SIENNA (03-99) / TOYOTA SOLARA (03-99) KIT 026 |
| 130 | 5235206 | BUICK ROADMASTER (93-92) / CADILLAC FLEETWOOD / BROUGHAM (93-90) / CHEVROLET CAPRICE (93-91) / CHEVROLET FULLSIZE PICK UP (95-87) / CHEVROLET G SERIE FULLSIZE VAN / EXPRESS (95-87) / CHEVROLET P SERIE VAN (95-87) / CHEVROLET SUBURBAN / FULLSIZE BLAZER / TAHOE (95-87) / GMC FULLSIZE PICKUP (95-87) / GMC G SERIE FULLSIZE VAN / SAVANA (95-87) / GMC P SERIE VAN (95-87) / GMC SUBURBAN / FULLSZE JIMMY / YUKON (95-87) / OLDSMOBILE DELTA 88 CUSTOM CRUISER / CUSTOM CRUISER (92) KIT 007 ó KIT 019 |
| 131 | 96518620 | DAEWOO MATIZ / SPARK KIT 030 |
| 132 | 0 280 155 811 | BUICK PARK AVENUE (05-96) / BUICK REGAL SEDAN / COUPE (04-97) / BUICK RIVIERA (99-96) / CHEVROLET IMPALA (05-04) / CHEVROLET MONTE CARLO (05-04) / CHEVROLET MONTE CARLO (05-04) / OLDSMOBILE LSS (99-97) / PONTIAC BONNEVILLE (03-96) / PONTIAC GRAND PRIX (03-97) KIT 001 ó KIT 047 |
| 133 | 0 280 156 053 | PORSCHE 911 SERIES (04-01) / PORSCHE BOXSTER (06-01) KIT 001 ó KIT 047 |



| | | |
|-----|------------------------------|---|
| 134 | 0 280 150 901 | <p>BUICK ELECTRA SEDAN / COUPE (90-88) / BUICK LESABRE SEDAN / COUPE (91-88) / BUICK REATTA (90-88) / BUICK RIVIERA (90-88) / OLDSMOBILE 98 / 98 REGENCY (90-88) / OLDSMOBILE DELTA 88 (91-88) / OLDSMOBILE TORONADO (90-88) / PONTIAC BONNEVILLE (91-88)</p> <p>KIT 001 ó KIT 034</p> |
| 135 | 4612176 | <p>CHRYSLER DYNASTY (93-92) / CHRYSLER NEW YORKER (93-92) / CHRYSLER TOWN & COUNTRY (93-92) / DODGE CARAVAN / GRAND CARAVAN (93-92) / DODGE DYNASTY (93-92) / PLYMOUTH VOYAGER / GRAND VOYAGER (93-92)</p> <p>KIT 001 ó KIT 021</p> |
| 136 | 9 250 930 018 35310-23010 | <p>HYUNDAI ELANTRA (98-96) / HYUNDAI TIBURON (97)</p> <p>KIT 002 ó KIT 031</p> |
| 137 | 9 250 930 006 | <p>HYUNDAI SCOUPE (93)</p> <p>KIT 002 ó KIT 031</p> |
| 138 | 0 280 150 759 CM4629 | <p>FORD AEROSTAR (89-87) / FORD BRONCO (89-87) / FORD BRONCO II (89-87) / FORD E SERIE FULLSIZE VAN (90-87) / FORD F SERIE FULLSIZE PICKUP (91-87) / FORD F SERIES MEDIUM DUTY PICKUP (91-90) FORD RANGER (89-87)</p> <p>KIT 001 ó KIT 034</p> |
| 139 | 0 280 156 061 06A906031BA | <p>AUDI TT SERIES (06-01) / VOLKSWAGEN GOLF (05) / VOLKSWAGEN JETTA (05-02)</p> <p>KIT 002 ó KIT 043</p> |



| | | |
|-----|---------------|--|
| 140 | 0 280 150 661 | CHEVROLET METRO (00-98) / GEO METRO (97-89) / SUZUKI SWIFT 4 CIL 1.3 LTS (97-95) KIT 203 |
| 141 | 0 280 158 001 | Ford E-150 (08-05) Ford E-150 Club Wagon (05) Ford E-250 (08-04) Ford E-250 Super Duty (05-04) Ford E-350 Club Wagon (05-04) Ford E-350 Super Duty (08-04) Ford E-450 Super Duty (09-06), (04) Ford Expedition (04-03) |
| 142 | 04591657AA | CHRYSLER CONCORDE (00) / CHRYSLER INTREPID (00) / DODGE INTREPID (00) KIT 001 |
| 143 | HONDA CIVIC | ACURA INTEGRA (95-92) / ACURA TL (96-95) / HONDA CIVIC (95-92) / HONDA CIVIC DEL SOL (95-93) KIT 014 Universal ó KIT 014 Original |
| 144 | 0 280 158 030 | |
| 145 | 25313185 | BUICK RAINIER (04) / CHEVROLET TRAILBLAZER (04-02) / GMC ENVOY (04-02) / ISUZU ASCENDER (04-03) / OLDSMOBILE BRAVADA (04-02) KIT 045 |



| | | |
|-----|------------------------------|---|
| 146 | 5235203 | BLAZER S10 4.3 LTS (88-94) <i>KIT 007 ó KIT 019</i> |
| 147 | 53032704AB | DODGE DAKOTA (07-01) / DODGE DURANGO (07-01) / DODGE DURANGO / FULLSIZE/ RAMCHARGER (07-02) / JEEP COMANCHE (07-06) / JEEP GRAN CHEROKEE (07-01) <i>KIT 001 ó KIT 021</i> |
| 148 | 0 280 156 300 | CHEVROLET CAPTIVA |
| 149 | AESJ22-5 | SUZUKY SWIFT 1.3 GTI |
| 150 | CDH 275 | MITSUBISHI DIAMANTE (04-00) / MITSUBISHI GALANT (99) / MITSUBISHI MONTERO SPORT (99-97) <i>KIT 028 ó KIT 029</i> |
| 151 | 9 260 930 004 35310-37150 | HYUNDAI ACCENT (09-06) / HYUNDAI SANTA FE (06-01) / HYUNDAI SONATA (05-99) / HYUNDAI TIBURON (08-03) HYUNDAYTUCSON (09-05) / KIA MAGENTIS (04-01) / KIA OPTIMA (06-02) / KIA RIO / RIO 5 (08-05) / KIA SPORTAGE (09-05) <i>KIT 002 ó KIT 043</i> |



| | | |
|-----|---------------|--|
| 152 | YL8E C7B | FORD ESCAPE (04-01) / FORD TAURUS (01) / MERCURY SABLE (01) |
| 153 | 23250-11100 | TOYOTA PASEO (95-92) <i>KIT 010</i> |
| 154 | 0 280 155 863 | LINCOLN LS (03-00) <i>KIT 001 ó KIT 047</i> |
| 155 | FJ340 | ACURA CL (99-97) / HONDA ACCORD (02-98) / HONDA CIVIC (00-99) |
| 156 | INP 774 | CHEVROLET GRAND VITARA XL7 (06-02) / SUZUKI GRAN VITARA (01) <i>KIT 028 ó KIT 029</i> |
| 157 | 0 280 155 807 | KIA SEPHIA (01-98) / KIA SPECTRA / SPECTRA5 (04-00) <i>KIT 002 ó KIT 043</i> |



| | | |
|-----|---------------|--|
| 158 | 0 280 150 917 | <p>BUICK LESABRE SEDAN ? COUPE (92) / BUICK PARK AVENUE (94-91) / BUICK REATTA (91) / BUICK REGAL SEDAN / COUPE (95-90) / BUICK RIVERA (93-91) / CHEVROLET LUMINA APV (92) / OLDSMOBILE 98 / 98 REGENCY (94-91) / OLDSMOBILE DELTA 88 (92) / OLDSMOBILE SILHOUETTE (92) / OLDSMOBILE TORONADO (92-91) / PONTIAC BONNEVILLE (92) / PONTIAC TRANS SPORT (92)</p> <p>KIT 001 ó KIT 034</p> |
| 159 | JS4J5 | <p>CHEVROLET TRACKER (04-01) / SUZUKI GRAN VITARA (05-99) / SUZUKI VITARA (04)</p> |
| 160 | 23250-70080 | <p>TOYOTA CRESSIDA (92-89) / TOYOTA SUPRA (92-89)</p> <p>KIT 010 ó KIT 020</p> |
| 161 | FJ443 | <p>ACURA CL (99) / ACURA INTEGRA (01-98) / ACURA RL (99-96) / ACURA TL (98-96) / HONDA ACCORD (02-98) / HONDA CIVIC (00-96) / HONDA CIVIC DEL SOL (97-96) / HONDA CR-V (98-97) / HONDA ODYSSEY (98) / ISUZU OASIS (99-98)</p> |
| 162 | NADA | |
| 163 | 0 280 150 415 | <p>BMW 323 SERIES (99-98) / BMW 325 SERIES (95-92) / BMW 525 SERIES (95-91) / BMW M SERIES (95)</p> <p>KIT 009 / KIT 036 / KIT 037</p> |



| | | |
|-----|-------------------|---|
| 164 | 4591308 | CHRYSLER 300 SERIES (99) / CHRYSLER CONCORDE (99-98) / CHRYSLER INTREPID (99-98) / CHRYSLER LHS (99) / DODGE INTREPID (99-98) / PLYMOUTH PROWLER (99) KIT 002 / KIT 001 / KIT 021 |
| 165 | YR3E A6A/9F593 | FORD F SERIES FULLSIZE PICKUP (02-99) / FORD MUSTANG (04-01) / FORD RANGE (04-01) / FORD TAURUS (05-01) / FORD WINDSTAR (03-99) / MAZDA PICKUP (03-01) KIT 001 ó KIT 021 |
| 166 | 04891573AB | CHRYSLER PT CRUISER (09-04) / CHRYSLER SEBRING (06-05) / DODGE CARAVAN / GRAND CARAVAN (07-04) / DODGE NEON (05-04) / DODGE STRATUS (06-05) KIT 002 |
| 167 | 0 280 156 023 | SAAB 9-3 (03-00) / SAAB 9-5 (09-00) KIT 002 ó KIT 043 |
| 168 | 195500-1970 | FORD PROBE (92-90) / KIA SEPHIA (97-95) / FORD LASER / MAZDA MIATA KIT 008 Universal ó KIT 008 Original |
| 169 | 25321369 | CHEVROLET CAVALIER (02-99) / CHEVROLET MALIBI (99) / OLDSMOBILE ALERO (01-99) / PONTIAC GRAND AM (01-99) / PONTIAC SUNFIRE (02-99) |



| | | |
|-----|---------------|---|
| 170 | 0 280 150 812 | <p>CHRYSLER DAYTONA (91-90) / CHRYSLER DYNASTY (90-88) / CHRYSLER LEBARON (91-90) / CHRYSLER NEW YORKER (90-88) / CHRYSLER TC MASERATI (91-90) / DODGE CARAVAN / GRAND CARAVAN (91-87) / DODGE DAYTONA (91-90) / DODGE DYNASTY (91-88) / DODGE MONACO (92-91) / DODGE SPIRIT (91-89) / DODGE VAN - MINI RAM (88-87) / EAGLE PREMIER (92-91) PLYMOUTH ACCLAIM (91-89) / PLYMOUTH VOYAGER / GRAND VOYAGER (91-87)</p> <p>KIT 001 ó KIT 021</p> |
| 171 | 25321668 | <p>CHEVROLET CAVALIER Z24 (02-99) / CHAVROLET MALIBU / MALIBU MAXX (99) / OLDSMOBILE ALERO (01-99) / PONTIAC GRAND AM (01-99) / POMTIAC SUNFIRE (02-99)</p> <p>KIT 015 / KIT 044 / KIT 039 / KIT 045</p> |
| 172 | 0 280 155 976 | <p>CHRYLER PT CRUISER (03-01) / CHRYSLER SEBRING (04-01) / CHRYSLER VOYAGER / GRANS VOYAGER (03-01) / DODGE CARAVAN / GRAND CARAVAN (03-01) / DODGE NEON ((03-01) / DODGE STRATUS (04-01) / PLYMOUTH NEON (01)</p> <p>KIT 002 ó KIT 043</p> |
| 173 | 0 280 155 861 | <p>FORD EXPLORER / SPORT / SPORT TRAC (01-99) / MAZDA MPV (01-00) / MERCURY CIUGAR (02-00) / MERCURY MOUNTAINEER (01-99)</p> <p>KIT 001 ó KIT 047</p> |
| 174 | 25358575 | <p>CHEVROLET COLORADO (05-04) / GMC CANYON (05-04)</p> <p>KIT 039 / KIT 017 / KIT 045 / KIT 046</p> |



| | | |
|-----|---------------|---|
| 175 | 53030343 | JEEP CHEROKEE (90-87) / JEEP COMANCHE (90-87) / JEEP WAGONEER (90-87) <i>KIT 001 ó KIT 021</i> |
| 176 | 23250-62040 | TOYOTA PRADO / TOYOTA 4RUNNER (02-99) / TOYOTA TACOMA (04-99) / TOYOTA TUNDRA (04-00) <i>KIT 026</i> |
| 177 | 0 280 155 735 | FORD AEROSTAR (97) / FORD EXPLORER / SPORT / SPORT TRAC (98-99) / FORD RANGER (97) / MAZDA PICKUP (99-97) <i>KIT 001 / KIT 047 / KIT 021 / KIT 048</i> |
| 178 | 12564446 | OPEL VECTRA 2.2 LTS 2002-2008 |
| 179 | INP 480 | FORD PROBE (97-93) / MAZDA 626 (99-93) / MAZDA MX-6 (97-93) <i>KIT 008</i> Universal ó <i>KIT 008</i> Original |
| 180 | 0 280 155 782 | CHRYSLER CIRRUS (00) / CHRYSLER SEBRING (99-98) / DOSGE NEON (00-98) / DODGE STRATUS (00-98) / PLYMOUTH BREEZE (00-98) / PLYMOUTH NEON (00-98) <i>KIT 002 ó KIT 043</i> |



| | | |
|-----|----------------------|---|
| 181 | 23250-74080 | TOTOTA VX 4500 4,5 LTS / LEXUX LX450 (97-96) / TOYOTA LAND CRUISER (97-93) KIT 020 |
| 182 | 17109826 17103007 | CHEVROLET CENTURY 3,1 LTS / BUICK CENTURY SEDAN / COUPE (99-94) / BUICK REGAL SEDAN / COUPE (96-94) / BUICK SKYLARK (98-94) / CHEVROLET BERETTA (96-94) / CHEVROLET CAMARO (95-93) / CHEVROLET CORSICA (96-94) / CHEVROLET LUMINA (99-95) / CHEVROLET MALIBU / MALIBU MAXX (99-97) / CHEVROLET MONTE CARLO (99-95) / OLDSMOBILE ACHIEVA (98-94) / OLDSMOBILE CIERA / CUTLASS CIERA (96-94) / OLDSMOBILE CITLAS / CUTLAS SUPREME (99-93) / PONTIAC FIREBIRD (95-93) / PONTIAC GRAND AM (98-94) / PONTIAC GRAND PRIX (99-94) / SATURN SC SERIES (00-96) / SATURN SL SERIES (00-96) / SATURN SW SERIES (01-96) KIT 001 |
| 183 | 53030778 | DODGE DAKOTA (02-96) / DODGE DURANGO (9-98) / DODGE PICKUP-FULLSIZE/RAMCHARGE (99-96) / DODGE VAN - FULLSIZE (99-96) / JEEP CHEROKEE (00-96) / JEEP GRAND CHEROKEE (98-96) / JEEP WRANGLER (02-97) KIT 021 |
| 184 | 0 280 156 007 | CHRYSLER TOWN & COUNTRY (07-01) / CHRYSLER VOYAGER / GRAND VOYAGER (03-01) / DODGE CARAVAN / GRAND CARAVAN (07-01) KIT 001 ó KIT 047 |
| 185 | 0 280 155 740 | CHRYSLER SEBRING (97) / DODGE NEON (97-96) / DODGE STRATUS (97) / PLYMOUTH BREEZE (97) / PLYMOUTH NEON (97-96) KIT 002 ó KIT 043 |



| | | |
|-----|---|---|
| 186 | INP 051 | <p>CHRYSLER DAYTONA (93-92) / CHRYSLER LEBARON (95-92) / CHRYSLER VOYAGER / GRANS VOYAGER (00) / DODGE CARAVAN / GRAND CARAVAN (00-92) / DODGE DAYTONA (93-92) / DODGE DYNASTY (93-92) / DODGE SHADOW (94-92) / DODGE SPIRIT (95-92) PLYMOUTH ACCLAIM (95-92) / PLYMOUTH SUNDANCE (94-92) / PLYMOUTH VOYAGER / GRANS VOYAGER (00-92)</p> <p>KIT 001 ó KIT 021</p> |
| 187 | INP 060 | <p>CHRYSLER CIRRUS (00-95) / CHRYSLER SEBRING (00-95) / DODGE AVENGER (00-95) / DODGE COLT (92-91) / DODGE STRATUS (00-95) / EAGLE SUMMIT (94-91) / EAGLE VISTA (91) / MITSUBISHI MIRAGE (92-91) / PLYMOUTH COLT (92-91)</p> <p>KIT 011</p> |
| 188 | rin 710 | |
| 189 | 25323971 | <p>BUICK CENTURY SEDAN / COUPE (05-00) / BUICK RENDEZVOUS (05-02) / CHEVROLET IMPALA (05-00) / CHEVROLET LUMINA (01-00) / CHEVROLET MALIBU / MALIBU MAXX (03-00) / CHEVROLET MONTE CARLO (05-00) / CHEVROLET VENTURE (05-00) / OLDSMOBILE ALERO (04-00) / OLDSMOBILE SILHOUETTE (04-00) / PONTIAC AZTEK (05-01) / PONTIAC GRAND AM (05-00) / PONTIAC GRAND PRIX (03-00) / PONTIAC MONTANA (05-00)</p> <p>KIT 015 / KIT 044 / KIT 039 / KIT 045</p> |
| 190 | <p>0 281 527 15 0 281 423 29 0 281 531 23</p> | |



| | | |
|-----|---------------|---|
| 191 | INP 059 | MITSUBISHI MX MF 2,0 LTS / EAGLE 2000 GTX (92-91) / EAGLE TALON (94-91) / MITSUBISHI ECLIPSE (94-91) / PLYMOUTH LASER (94-91) KIT 003 |
| 192 | F2TE A3A | FORD BRONCO (91-85) / FORD E SERIE FULLSIZE VAN (99-86) / FORD F SERIE FULLSIZE PICKUP (91-85) / FORD MUSTANG (95-86) / FORD THUNDERBIRD (93-91) / LINCOLN MARK SERIE (92-90) / MERCURY CAPRI (86) / MERCURY COUGAR (93-91) KIT 021 ó KIT 005 |
| 193 | INP 532 | DOSGE STEALTH (96-94) / MITSUBISHI 3000GT (99-95) / MITSUBISHI DIAMANTE (95-94) KIT 028 ó KIT 029 |
| 194 | 0 280 150 504 | KIA SPORTAGE (02-95) (ANARANJADO) KIT 053 |
| 195 | 0 280 150 502 | KIA SPORTAGE (02-95) (VERDE) KIT 053 |
| 196 | 0 280 156 159 | NISSAN SENTRA (06-03) KIT 002 ó KIT 043 |



| | | |
|-----|---------------|---|
| 197 | INP 781 | MAZDA PROTEGE / MAZDA 626 Y MAZDA ALLEGRO / FORD LASER (99-02) (AZUL) KIT 028 |
| 198 | INP 780 | MAZDA PROTEGE / MAZDA 626 Y MAZDA ALLEGRO / FORD LASER (99-02) (MARRON) KIT 028 |
| 199 | 17122106 | CHEVROLET CAVALIER (99-98) / CHEVROLET S10 (00-98) / GMC SONOMA (00-98) / ISUZU HOMBRE (00-98) / PONTIAC SUNFIRE (99-98) / SATURN SC2 (95-93) / SATURN SL2 (95-93) / SATURN SW2 (95-93) |
| 200 | 17109450 | DAEWOO CIELO 1,5 LTS |
| 201 | 0 280 156 029 | FORD EXPLORER (03-01) / FORD EXPLORER SPORT TRAC (03-02) / FORD RANGE (03-01) / MAZDA B4000 (03-01) / MERCURY MOUNTAINEER (03-01) |
| 202 | 23250-28020 | TOYOTA CAMRY (03-02) / TOYOTA HIGHLANDER (03-01) / TOYOTA SOLARA (03-02) |



| | | |
|-----|---------------|--|
| 203 | 90536149 | CHEVROLET ASTRA / OPEL VECTRA |
| 204 | 0 280 156 156 | |
| 205 | 0 280 155 703 | CHRYSLER CIRRUS (97-95) / CHRYSLER SEBRING (97-96) / DODGE CARAVAN (97-96) / DODGE GRAN CARAVAN (97-96) / DODGE NEON (97-95) / DODGE STRATUS (97-95) / PLYMOUTH BREEZE (97-96) / PLYMOUTH GRAN VOYAGER (97-96) / PLYMOUTH NEON (97-95) / PLYMOUTH VOYAGER (97-96) |
| 206 | 23250-76010 | TOYOTA PREVIA (95-91) |
| 207 | YF1E-F4C | FORD TAURUS (07-00) / MERCURY SABLE (05-00) |
| 208 | 195500-3970 | MITSUBISHI MONTERO (02-01) |



| | | |
|-----|---------------|--|
| 209 | 25317628 | CHEVROLET SILVERADO 1500 (07-01) / SILVERADO 2500 (04-99) / TAHOE (06-00) / TRAIL BLAZER (06-03) |
| 210 | 25325012 | CHEVROLET S10 (03-00) / GMC SONOMA (03/00) |
| 211 | E67E-B4B | FORD AEROSTAR (91-86) / FORD BRONCO (92-87) / FORD BRONCO II (90-86) / FORD COUNTRY SQUIRE (91-87) / FORD E-150 ECONOLINE (96-87) / FORD E-150 ECONOLINE CLUB WAGON (96-87) / FORD E-250 ECONOLINE (96-87) / FORD E-250 ECONOLINE CLUB WAGON (91-87) / FORD E-350 ECONOLINE (96-87) / FORD E-350 ECONOLINE CLUB WAGON (96-87) / FORD ESCORT (96-91) / FORD MUSTANG (98-91) |
| 212 | 25319306 | CHEVROLET CAVALIER (02-00) / PONTIAC SUNFIRE (02-00) |
| 213 | 195500-0733 | BUICK SOMERSET REGAL (85) / FORD AEROSTAR (91-86)/ FORD PROBE (92-90)/ FORD RANGER (91)/ FORD TAURUS (91-86)/ MAZDA B3000 (97)/ MERCURY SABLE (90-86)/ MERKUR SCORPIO (89-88)/ OLDSMOBILE CALAIS (85)/ PONTIAC GRAND AM (85) |
| 214 | 0 280 150 941 | FORD AEROSTAR (91-86) / FORD BRONCO (92-87) / FORD BRONCO II (90-86) / FORD COUNTRY SQUIRE (91-87) / FORD E-150 ECONOLINE (96-87) / FORD E-150 ECONOLINE CLUB WAGON (96-87) / FORD E-250 ECONOLINE (96-87) / FORD E-250 ECONOLINE CLUB WAGON (91-87) / FORD E-350 ECONOLINE (96-87) / FORD E-350 ECONOLINE CLUB WAGON (96-87) / FORD ESCORT (96-91) / FORD MUSTANG (98-91) |



| | | |
|-----|---------------|--|
| 215 | F1ZE-B4C | FORD AEROSTAR (91-86) / FORD BRONCO (92-87) / FORD BRONCO II (90-86) / FORD COUNTRY SQUIRE (91-87) / FORD E-150 ECONOLINE (96-87) / FORD E-150 ECONOLINE CLUB WAGON (96-87) / FORD E-250 ECONOLINE (96-87) / FORD E-250 ECONOLINE CLUB WAGON (91-87) / FORD E-350 ECONOLINE (96-87) / FORD E-350 ECONOLINE CLUB WAGON (96-87) / FORD ESCORT (96-91) / FORD MUSTANG (98-91) |
| 216 | 23250-70040 | TOYOTA CRESSIDA (92-89)/ TOYOTA SUPRA (92-89) |
| 217 | 195500-2180 | MAZDA B2200 (93-90) |
| 218 | 04891577AB | CHRYSLER 200 (12-11) / CHRYSLER SEBRING (10-07) / DODGE AVENGER (12-08) / DODGE CALIBER (12-07) / DODGE JOURNEY (11-09) / JEEP COMPASS (11-07) / JEEP PATRIOT (12-07) |
| 219 | 0 280 158 056 | |
| 220 | 0 280 158 055 | |



| | | |
|-----|---------------|---|
| 221 | 0 280 150 432 | SAAB 900 (98-94) / SAAB 9000 (94) |
| 222 | F57E-B2C | |
| 223 | 23250-65010 | TOYOTA 4RUNNER (88) / TOYOTA PICKUP (88) |
| 224 | 23250-28050 | TOYOTA RAV4 (03-01) |
| 225 | 0 280 155 857 | FORD CROWN VICTORIA (99) / FORD E-350 ECONOLINA (99) / FORD E-350 ECONOLINE CLUB WAGON (99) / FORD ECONOLINE SUPER DUTY (99) / FORD F-250 SUPER DUTY (99) / FORD F-350 SUPER DUTY (99) / FORD F-450 SUPER DUTY (99) / FORD F-550 SUPER DUTY (99) LINCOLN TOWN CAR (99) / MERCURY GRAND MARQUIS (99) |
| 226 | F65E-A4A | FORD E-150 ECONOLINE (98-97) / FORD E-150 ECONOLINE CLUB WAGON (98-97) / FORD E-250 ECONOLINE (98-97) / FORD F-150 (98-97) / FORD WINDSTAR (97-96) |



| | | |
|-----|---------------|--|
| 227 | 0 280 150 779 | VOLVO 850 (97-94) |
| 228 | 195500-3040 | KIA SEPHIA (97) / MAZDA PROTEGE (98-97) |
| 229 | 23250-46090 | LEXUS ES300 (01-98) / LEXUS RX300 (03-99) / TOYOTA AVALON (04-98) / TOYOTA CAMRY (01-98) / TOYOTA HIGHLANDER (03-01) / TOYOTA SIENNA (03-99) / TOYOTA SOLARA (03-99) |
| 230 | XR82-AD | JAGUAR VANDEN PLAS (03-98) / JAGUAR XJ8 (03-98) / JAGUAR XK8 (02-99) |
| 231 | JS23-4 | INFINITI QX4 (00-97) / MERCURY VILLAGER (02-96) / NISSAN FRONTIER (04-99) / NISSAN PATHFINDER (00-96) / NISSAN QUEST (02-96) / NISSAN XTERRA (04-00) |
| 232 | INP-783 | MAZDA PROTÉGÉ (03-01) / MAZDA PROTEGE5 (03-02) |



| | | |
|-----|---------------|---|
| 233 | 0 280 156 028 | FORD EXPLORER (03-01) / FORD EXPLORER SPORT TRAC (03-02) / FORD RANGE (03-01) / MAZDA B4000 (03-01) / MERCURY MOUNTAINEER (03-01) |
| 234 | 1L5E-C4B | FORD RANGE (08-01) / MAZDA B3000 (07-01) |
| 235 | 23250-74040 | TOYOTA CELICA (91-90) / TOYOTA MR2 (92-91) |
| 236 | 23250-50020 | LEXUS LS400 (97-93) / LEXUS SC400 (97-92) |
| 237 | 195500-3260 | CHEVROLET METRO (01-98) / SUZUKI SWIFT (01-98) |
| 238 | 23250-22010 | CHEVROLET PRIZM (99-98) / ISUZU AXIOM (03-02) / ISUZU RODEO (04-03) / ISUZU VHCROSS (01-99) / TOYOTA COROLLA (99-98) |



| | | |
|-----|--------------------------|--|
| 239 | 0 280 155 991 | MINI COOPER (08-02) |
| 240 | 0 280 150 947 | 249CC/MIN (23.7 LBS/HR) @ 43.5 PSI 14.5 OHM |
| 241 | 5094205602 | DAEWOO CIELO DOHC 2.0LTS |
| 242 | F55E-A2E | FORD MUSTANG (99-96) / LINCOLN CONTINENTAL (98-95) / LINCOLN MARK VIII (98-96) |
| 243 | 23250-31050 | LEXUS ES350 (11-07) / LEXUS RX350 (10-07) / TOYOTA AVALON (11-05) / TOYOTA CAMRY (11-07) / TOYOTA HIGHLANDER (10-08) / TOYOTA RAV4 (11-06) / TOTOTA IENNA (10-07) / TOYOTA VENZA (11-09) |
| 244 | 04861238AA 04861238AC | CHRYSLER PACIFICA (08-05) / CHRYSLER TOWN & COUNTRY (07-01) / DODGE GRAND CARAVAN (07-01) |



| | | |
|-----|---------------|--|
| 245 | JS4D | NISSAN FRONTIER (04-98) / NISSAN PICKUP (97-96) / NISSAN XTERRA (04-00) |
| 246 | 17109448 | BUICK CENTURY (99-94) / BUICK REGAL (96-94) / BUICK SKYLARK (98-94) CHEVROLET BERETTA (96-94) / CHEVROLET CAMARO (95-93) / CHEVROLET CORSICA (96-94) / CHEVROLET LUMINA (99-95) / CHEVROLET MALIBU (99-97) / CHEVROLET MONTE CARLO (99-95) / OLDSMOBILE ACHIEVA (98-94) / OLDSMOBILE CUTASS (99-97) / OLDSMOBILE CUTTLAS CIERA (96-94) / OLDSMOBILE CUTLASS CRUISER (94) / OLDSMOBILE CUTLASS SUPREME |
| 247 | NADA | |
| 248 | PA66GF35 | FORD F-150 (08-07) / FORD F-250 SUPER DUTY (10-08) / FORD F-350 SUPER DUTY (10-08) / LINCOLN MARK LT (08) |
| 249 | 53007232 | JEEP CHEROKEE (95-91) / JEEP COMANCHE (92-91) / JEEP WRANGLER (95-91) |
| 250 | 0 280 150 955 | VOLKSWAGEN CABRIO (02-95) / VOLKSWAGEN GOLF (00- 93) / VOLKSWAGEN JETTA (99-93) / VOLKSWAGEN PASSAT (96-95) |



| | | |
|-----|-------------|---|
| 251 | 23250-97401 | TOYOTA TERIOS |
| 252 | JS28-4 | CHEVROLET WAGON R / SUZUKI VITARA |
| 253 | INP 771 | CHEVROLET TRACKER (03-99) / SUZUKI VITARA (03-99) |
| 254 | JS50-1 | NISSAN PRIMERA Y NISSAN SENTRA B14 |
| 255 | IWM500.01 | RENAULT Y VOLKSWAGEN |
| 256 | 25335146 | |



| | | |
|-----|--------|------------------------|
| 257 | IWP001 | FIAL UNO 1,6 LTS |
| 258 | IWP044 | VOLKSWAGEN GOL 1,6 LTS |
| 259 | IWP143 | RENAULT 1,6 LTS |
| 260 | IWP157 | FIAL SIENA 1.8 LTS |
| 261 | IWP114 | VOLKSWAGEN GOL 1,8 LTS |
| 262 | IWP099 | RENAULT |



| | | |
|-----|---------------|---|
| 263 | IWP071 | MERCEDEZ BENZ |
| 264 | 12580681 | BUICK RAINIER (07-05) / CADILLAC SCALADE (09-07) / CHEVROLET AVALANCHE (09-07) / CHEVROLET AVALANCHE 1500 (06) / CHEVROLET COLORADO (09) / CHEVROLET EXPRESS 2500 (09-08) / CHEVROLET EXPRESS 3500 (09-08) / CHEVROLET EXPRESS 4500 (09) / CHEVROLET SILVERADO 1500 (09-07) / CHEVROLET SILVERADO 2500 HD (08) / CHEVROLET SILVERADO 3500 HD (08) / CHEVROLET SSR (06-05) / CHEVROLET SUBURBAN 1500 (09-07) / CHEVROLET |
| 265 | 12592648 | BUICK LUCERNE (10-09) / BUICK TERRAZA (07-06) / BUICK IMPALA (10-06) / CHEVROLET MALIBU (09-06) / CHEVROLET MONTE CARLO (07-06) / CHEVROLET UPLANDER (09-06) / PONTIAC G6 (10-06) / PONTIAC MONTANA (06) / SATURN AURA (08-07) / SATURN RELAY-1 (07) / SATURN RELAY-2 (07) / SATURN RELAY-3 (07-06) / SATURN VUE (10-08) |
| 266 | 0 280 155 995 | VOLKSWAGEN BEETLE (03-02) / VOLKSWAGEN GOLF (02-01) / VOLKSWAGEN JETTA (03-01) |
| 267 | 04854181 | DODGE DURANGO (00) / DODGE RAMM 1500 (01-00) / DODGE RAM 1500 VAN (03-00) / DODGE RAM 2500 VAN (03-00) / DODGE RAM 3500 VAN (03-00) / JEEP CHEROKEE (01-99) / JEEP GRAN CHEROKEE (04-99) / JEEP TJ (04-99) / JEEP WRANGLER (04-99) |
| 268 | 01F002A | PEUGEOT 206 1,4 LT / TATA |



| | | |
|-----|---------------|---|
| 269 | 0 280 155 789 | CHRYSLER GRAN VOYAGER (00) / CHRYSLER TOWN & COUNTR (00-99) / CHRYSLER VOYAGER (00) / DODGE CARAVAN (00-98) / DODGE GRAN CARAVAN (00-98) / PLYMOUTH GRAN VOYAGER (00-98) / PLYMOUTH VOYAGER (00-98) |
| 270 | 35310-25200 | HYUNDAI ACCENT (11-06) / HYUNDAI SANTA FE (06-01) / HYUNDAI SONATA (05-99) / HYUNDAI TUBURON (08-03) / HYUNDAI TUCSON (09-05) / KIA MAGNETIS (04-01) / KIA OPTIMA (06-01) / KIA RIO (10-05) / KIA RIO5 (10-06) / KIA SPORTAGE (10-05) |
| 271 | 23250-62020 | LEXUS 1990-91 ES250 2,5 LTS / TOYOTA CAMRY 88-91 2,5 LTS |
| 272 | 0 280 156 245 | FORD EXPLORER (04) / FORD EXPLORER SPORT TRAC (04) / MERCURY MOUNTAINEER (04) |
| 273 | 6900371 | VOLVO S40 (04-01) / VOLVO V40 (04-01) |
| 274 | 23250-28080 | SCION TC (10-05) / SCION XB (11-08) / TOYOTA CAMRY (09-04) / TOYOTA COROLLA (10-09) / TOYOTA HIGHLANDER (07-04) / TOYOTA MATRIX (11-09) / TOYOTA RAV4 (08-04) / TOYOTA SOLORA (08-04) |



| | | |
|-----|------------------------------|--|
| 275 | 23250-0H010 | TOYOTA CAMRY (03-02) / TOYOTA HIGHLANDER (03-01) / TOYOTA SOLARA (03-02) |
| 276 | 9 260 930 057 35310-37170 | HYUNDAI ACCENT (11-06) / KIA RIO (11-09) / KIA RIO5 (11-09) |
| 277 | 17103146 | BUICK LESABRE (00-96) / BUICK PARK AVENUE (00-98) / CHEVROLET CAMARO (99-95) / OLDSMOBILE 88 (99-96) / OLDSMOBILE LSS (99-96) / OLDSMOBILE REGENCY (98-97) / PONTIAC BONNEVILLE (00-96) / PONTIAC FIREBIRD (99-95) |
| 278 | 0 280 156 010 | FORD FOCUS (00) |
| 279 | 17089166 | DAEWOO |
| 280 | 0 280 158 007 | INFINITI QX56 (10-04) / NISSAN ARMADA (11-05) / NISSAN FRONTIER (11-05) / NISSAN PATHFINDER (11-04) / NISSAN TITAN ((11-04) / NISSAN XTERRA (11-05) / SUZUKI EQUATOR (11-09) |

Standard Motor Products, Inc.



Standard Motor Products, Inc.



Standard Motor Products, Inc.



| | | |
|-----|---------------|--|
| 281 | HONDA | HONDA CR-V (01-99) |
| 282 | 23250-65020 | TOYOTA 4RUNNER (95-89) / TOYOTA PICKUP (95-89) / TOYOTA T100 (94-93) |
| 283 | 17113782 | VORTEC INJECTOR |
| 284 | 0 280 158 101 | CHEVROLET OPTRA |
| 285 | IWP127 | ECO SPORT-FORD FIESTA |
| 286 | IWP065 | FIAT FIRE 1.3 LTS |

Standard Motor Products, Inc.



| | | |
|-----|----------|--|
| 287 | 17124782 | CORSA 1.3 Y 1.6 |
| 288 | 17103677 | DAEWOO CIELO |
| 289 | 97MFBA | FORD FIESTA ZETEC 1.25 LTS |
| 290 | RENAULT | RENAULT |
| 291 | XF2E-C4B | Ford F-150 (02) Ford F-150 (99) Ford Mustang (04-01) Ford Windstar (03-99) Ford Taurus (05-01) Ford Ranger (04-01) Mazda B3000 (03-01) |
| 292 | INP-470 | INYECTOR VITARA 1.6 GEO TRACKER SUZUKI SIDE KICK |



| | | |
|-----|-------------------------------------|--|
| 293 | H274263 / ITG048 / 1207P04104 | INJECTOR RENAULT CLIO 1.2 / KANGOO 1.6 |
| 294 | 53032713AB | Dodge Durango (09-04) Dodge Ram 2500 (08-04) Dodge Ram 1500 (08-04) Dodge Ram 3500 (08-04) Chrysler Aspen (08-07) |
| 295 | 3W43-AA | Ford Taurus (07-00) Mercury Sable (05-00) |
| 296 | 280155923 | Cadillac Eldorado (02-00) Cadillac DeVille (05-00) Oldsmobile Aurora (03-01) Pontiac Bonneville (05-04) Cadillac Seville (04-00) |
| 297 | 280158105 | Ford Fusion (09-06) Mercury Milan (09-06) Ford Ranger (11-07) |
| 298 | JS20-1 | Mercury Villager (95-93) Nissan Quest (95-93) Nissan Pathfinder (95-90) Nissan Pickup (96-95) Nissan D21 (94-90) |



| | | |
|-----|------------|---|
| 299 | 12588610 | Buick Terraza (07-06) Chevrolet Monte Carlo (07-06) Chevrolet Uplander (09-06) Pontiac Montana (09-06) Saturn Aura (08-07) Saturn Vue (10-08) Buick Lucerne (10-09) Chevrolet Impala (10-06) Chevrolet Malibu (09-06) Pontiac G6 (10-06) Saturn Relay (07-06) |
| 300 | 280156034 | PEUGEOT 206 |
| 301 | 12613163 | Chevrolet HHR (11-09) Chevrolet Malibu (12-10) Pontiac G6 (10) |
| 302 | 0 | 0 |
| 303 | FBJCB00 | CHEVROLET LUV DMAX |
| 304 | 078133551L | Audi A4 (01-97) Audi A6 Quattro (98) Audi A4 Quattro (01-98) Audi A6 (01-99) Audi A6 (98) Volkswagen Passat (01-98) Audi A6 Quattro (01-99) |



| | | |
|-----|-----------|--|
| 305 | 12586557 | Buick Rendezvous (07-06) Buick Terraza (06-05) Chevrolet Malibu (06-04) Chevrolet Uplander (06-05) Pontiac Montana (06-05) Pontiac G6 (06-05) Saturn Relay (06-05) |
| 306 | INP-018 | Chrysler Sebring (96-95) Eagle Talon (98-95) Mitsubishi Eclipse (99-95) |
| 307 | 96620255 | CHEVROLET SPARK |
| 308 | 280156152 | INYEKTOR CORSA MERIVA 1.8 |
| 309 | FJ286 | Nissan Maxima (94-93) |



| | | |
|-----|----------|---|
| 310 | FJ146 | Nissan 300ZX (94-90) |
| 311 | FJ150 | Nissan Maxima (92-89) |
| 312 | 17104224 | Buick Skylark (95) Chevrolet Cavalier (95) Oldsmobile Achieva (95) Pontiac Grand Am (95) Pontiac Sunfire (95) |
| 313 | FJ490 | Acura MDX (02-01) Acura CL (03-01) Acura TL (03-00) Honda Odyssey (04-02) Honda Pilot (04-03) |
| 314 | FJ262 | Acura NSX (03-95) Honda Accord (95-94) |
| 315 | FJ743 | Acura NSX (05-97) |



| | | |
|-----|-------------|--|
| 316 | FJ337 | Honda Civic (00-96) Honda Civic del Sol (97-96) |
| 317 | 23250-21040 | TOYOTA YARIS |
| 318 | 23250-31010 | Toyota Tacoma (13-07) Toyota Tundra (11-07) |
| 319 | 12790827 | Saab 9-3 (05-03) |
| 320 | INP-533 | Dodge Stealth (96-94) Mitsubishi 3000GT (99-95) Mitsubishi Diamante (95-94) |
| 321 | 280156048 | Ford Crown Victoria (04-01) Lincoln Town Car (02-01) Mercury Grand Marquis (02-01) |



| | | |
|-----|-------------|---|
| 322 | 280155848 | Saturn L300 (05-01) Saturn LS2 (00) Saturn LW2 (00) Saturn LW300 (03-01) |
| 323 | 078133551BA | Audi A4 (01-97) Audi A4 Quattro (01-98) Audi A6 (01-99) Audi A6 (98) Audi A6 Quattro (01-99) Audi A6 Quattro (98) Volkswagen Passat (01-98) |
| 324 | 000 0788523 | Mercedes-Benz |
| 325 | 280155937 | Nissan Sentra (02-00) |
| 326 | 1x43-ab | JAGUAR X TYPE 2.5 / 3.0 (220-2008) |
| 327 | 280158130 | Nissan Altima (13-07) Nissan Rogue (13-08) Nissan Sentra (12-07) |



| | | |
|-----|------------|---|
| 328 | 94013014 | Nissan Altima (13-07) Nissan Rogue (10-08) |
| 329 | 12569091 | Chevrolet Cavalier (02) Chevrolet Classic (05-04) Oldsmobile Alero (04-02) Pontiac Grand Am (05-02) Pontiac Sunfire (02) Saturn L100 (02-01) Saturn L200 (03-01) Saturn L300 (04) Saturn LS (00) Saturn LS1 (00) Saturn LW1 (00) Saturn LW200 (03-01) |
| 330 | 04591306ab | Chrysler Concorde (00) Chrysler Intrepid (00) Dodge Intrepid (00) |
| 331 | 280156131 | Cadillac CTS (09-07) Cadillac SRX (09-07) Cadillac STS (07) Chevrolet Equinox (09-08) Chevrolet Malibu (12-08) Pontiac G6 (09-07) Pontiac G8 (09-08) Pontiac Torrent (09-08) Saturn Aura (09-07) |
| 332 | f78e-a4a | Ford Windstar (98) |
| 333 | FO3E-A2B | Ford Aerostar (97-92) Ford Probe (92-91) Ford Ranger (01-92) Ford Taurus (99-91) Ford Tempo (94-92) Ford Windstar (00-95) Mazda B2300 (94) Mazda B2500 (01-98) Mazda B3000 (96-94) Mercury Sable (99-91) Mercury Topaz (94-92) |



| | | |
|-----|-----------|---|
| 334 | 280150927 | Dodge B150 (94) Dodge B1500 (96-95) Dodge B250 (94) Dodge B2500 (96-95) Dodge Dakota (96-94) Dodge Ram 1500 (96-94) |
| 335 | 280156182 | Chevrolet Equinox (09-05) Pontiac Torrent (09-06) |
| 336 | FOTE-D5A | Ford Bronco (96-90) Ford Crown Victoria (97-92) Ford E-150 (04-03) Ford E-150 Club Wagon (04-03) Ford E-150 Econoline (02-90) Ford E-150 Econoline Club Wagon (02-90) Ford E-250 (04-03) Ford E-250 Econoline (02-90) Ford E-250 Econoline Club Wagon (91-90) Ford E-250 Super Duty (04) Ford E-350 (03) Ford E-350 Club Wagon (04-03) Ford E-350 Econoline (02-90) Ford E-350 Econoline Club Wagon (02-90) Ford E-350 Super Duty (04) Ford E-450 Econoline Super Duty (02-00) Ford E-450 Super Duty (03) Ford Econoline Super Duty (98-96) Ford Excursion (05-00) Ford Expedition (02-97) Ford F-150 (03-89) Ford F-250 (99-89) Ford F-250 Super Duty (03-99) Ford F-350 (97-89) Ford F-350 Super Duty (03-99) Ford Mustang (04-96) Ford Thunderbird (94) Lincoln Navigator (99-98) Lincoln Town Car (94-91) Mercury Cougar (94) Mercury Grand Marquis (97-92) |
| 337 | 9470199 | Volvo S40 (00) Volvo V40 (00) |
| 338 | 280155787 | Land Rover Discovery (04-99) Land Rover Range Rover (02-99) |



| | | |
|-----|------------|---|
| 339 | 96487553 | Chevrolet Aveo (08-07) Chevrolet Aveo5 (08-07) Pontiac G3 (09) |
| 340 | 280158005 | Nissan Altima (06-04) Nissan Maxima (08-03) Nissan Murano (04) Nissan Quest (09-04) |
| 341 | 280155700 | Ford Contour (98) Ford Crown Victoria (98) Ford E-350 Econoline (99-97) Ford E-350 Econoline Club Wagon (99-97) Ford Econoline Super Duty (99-97) Ford Explorer (98-96) Ford F-250 Super Duty (99) Ford F-350 Super Duty (99) Ford Thunderbird (97-94) Lincoln Town Car (98-95) Mercury Cougar (97-94) Mercury Grand Marquis (98) Mercury Mountaineer (98-97) Mercury Mystique (98-96) |
| 342 | 07813355in | Audi A4 (99-98) Audi A4 Quattro (99-98) Volkswagen Passat (99-98) |
| 343 | 17122105 | Buick Century (93-87) Buick Regal (93-88) Buick Skylark (93-89) Cadillac Cimarron (88-87) Chevrolet Beretta (93-87) Chevrolet Camaro (92-90), (88-85) Chevrolet Cavalier (94-87) Chevrolet Celebrity (90-85) Chevrolet Corsica (93-87) Chevrolet Lumina (94-90) Dodge Atos (12-01) Oldsmobile Achieva (93-92) Oldsmobile Cutlass Calais (91-89) Oldsmobile Cutlass Ciera (93-86) Oldsmobile Cutlass Cruiser (93-87) Oldsmobile Cutlass Supreme (93-88) Oldsmobile Firenza (87) Pontiac 6000 (91-85) Pontiac Firebird (92-90), (88-85) Pontiac Grand Am (93-92) Pontiac Grand Prix (93-88) Pontiac Sunbird (94-91) Pontiac Tempest (91-87) |



| | | |
|-----|-------------|---|
| 344 | 17106772 | Cadillac DeVille (95) Cadillac Eldorado (95) Cadillac Seville (95) Oldsmobile Aurora (95) |
| 345 | INP-062 | Dodge Colt (94-93) Eagle Summit (96-93) Mitsubishi Mirage (96-93) Plymouth Colt (94-93) |
| 346 | XL5E-A2A | Ford Ranger (00-98) Mazda B3000 (99-98) |
| 347 | 195500-5690 | MAZDA Y MITSUBISHI 1997 3.5 lt |
| 348 | 0 | 0 |
| 349 | FJTJ14 | DAEWOO RACER |



350

25342385

CORSA, MERIVA, MONTANA, CHEVY, FIAT, IDEA, PALIO,
SIENA, PUNTO 2006 1.5 1.6 1.8 LTS (45ml AS)

